

BVMS license upgrade to BVMS 11.0

Hepting Manuel (BT-VS/XSW-AIA) 27 May, 2021 Author:

Date:

1	Document history	3
2	Upgrade with Software Assurance PRO to BVMS 11.0	4
2.1	Introduction	4
2.2	Glossary	4
2.3	Check software assurance status in the Bosch Software License Manager System (SLMS)	5
2.4	Upgrade license to BVMS 11.0	6
2.5	Start the upgrade process	7
2.6	Data transfer from the Bosch Software License Manager System to the Bosch Remote Portal	9
3	BVMS initial license activation	10

1 Document history

Date	Version	Changes
2021-05-25	Version 1.0	Inital White Paper: BVMS license upgrade to BVMS 11.0

2 Upgrade with Software Assurance PRO to BVMS 11.0

2.1 Introduction

This document describes how you can migrate existing activated BVMS licenses from the Bosch Software License Manager System (SLMS) licensing system to the new Bosch Remote Portal licensing.

In general only systems with a valid Software Assurance (SMA) PRO can upgrade to the next BVMS version. You can check the software assurance status in the SLMS system. In case the software assurance is expired, order an SMA expansion for your system.

Note:


With the new licensing technology in BVMS 11.0, BVMS uses a new algorithm to create the unique identifier of the system. This identifier is called "fingerprint". Because of the new algorithm to generate the unique identifier, you can not upgrade the licenses directly with the upgrade process. The upgrade process generates a new software order ID that you have to activate manually in the Remote Portal together with the new unique identifier.

2.2 Glossary

Changes in the terms for licensing:








2.3 Check software assurance status in the Bosch Software License Manager System (SLMS)

To check the software assurance status of the system in SLMS, open the **License Status** page in SLMS and enter either the **Authorization Number**, **Activation Number** or **Hardware Id**.



If the system has a valid software assurance status until the official release date of BVMS 11.0, you can upgrade the system to BVMS 11.0!


2.4 Upgrade license to BVMS 11.0

To start the upgrade process to BVMS 11.0, search for the system under My Activations:




If a system is entitled to upgrade to the next BVMS version, the **Upgrade** button is available. In this example the red marked system has a valid maintenance agreement to upgrade to BVMS 11.0. The other systems are not allowed to upgrade to BVMS 11.0.

When you click the **Upgrade** button, the migration process of the license from SLMS to Remote Portal starts.




2.5 Start the upgrade process


In order to start the upgrade process, click the Upgrade button of the system:




The SLMS system starts the upgrade process. During collecting data and creating the software order ID, the system displays **Upgrading...**.



Once the upgrade is finished, the system displays the following information:



When you click + next to the hardware ID, you see the software order ID:



In order to activate the BVMS 11.0 license, copy the software order ID and start the activation process in Bosch Remote Portal.

2.6 Data transfer from the Bosch Software License Manager System to the Bosch Remote Portal

During the license upgrade from BVMS 10.1 to BVMS 11.0, the license migrates from the SLMS system to the Remote Portal system. The following data transfers from the SLMS System to the Remote Portal system:

- · All active licenses on the computer signature
- · Software assurance end date
- · Assigned country to the SLMS user ID

Not visible for users, only transferred for documentation reason:

- The old unique identifier of the BVMS system, called computer signature
- User ID of the SLMS user that requests the migration
- · Order number of the base package

3 BVMS initial license activation

Introduction

This section describes the initial license activation process of BVMS licenses.


Follow these steps:

- Collect system info file from the BVMS system
- · Claim ownership of the software order ID in the Remote Portal
- · Activate the software order ID with the system info file in Remote Portal and download the activation file
- · Add the activation file to the BVMS system to enable the software

How to get started

Open your BVMS Configuration Client application and sign in with the BVMS administrator user account.

After you successfully logged in, you see the following BVMS message. It tells you that the system is currently running in an unregistered mode and that you have to activate your license package.



Directly click on **OK**. Since you want to initially activate a license, the license status is "not activated".

Activate a license



To obtain an active license you need to execute the following steps:

Step 1: Click Add... to enter the Add license dialog


Step 2: Save your system info to a file

Click the Save button and a file with the system info is created. Safe the system info file on your computer.

Note: If you do not have internet access on the computer where your BVMS application is installed, transfer the system info file to a computer with internet connection.

Step 3: Go to remote.boschsecurity.com to generate your activation file


Click the link and the Bosch Remote Portal website displays. You can either sign up or login in case you already have a user account.



In case of an initial user account creation, please click **Sign Up**, fill in the required information and select the terms of agreement check boxes. After your account is successfully created, you can login to the Bosch Remote Portal.

Step 4: Follow the instructions on remote.boschsecurity.com/softwarelicensing to generate your activation file by uploading your system info.


Click the link in **Step 3** or directly go to the **Software Licensing** tab in the Remote Portal toolbar. The following screen displays:



Step 5: Claim the ownership of the software order ID in Remote Portal


The software order ID can be obtained by placing a software order or by a upgrading a license from the Bosch Software License Manager System.

In order to claim the ownership of the software order ID, click **Claim Software Order** in the bottom right corner of the display. The **Claim Software Order** window displays. Click **Claim**.




Step 6: Activate a license


In order to activate a license, click **Activate License** in the bottom right corner of the display. The **Activate License** window opens. Upload the system info file that you saved earlier and fill in the required information.



Select the base package to activate it:




Select the expansion licenses and the quantity to activate them:



Step 7: Download your activation file and make it accessible to the BVMS computer


After you successfully added your license, you will see the following license dashboard in the Remote Portal. Click **Download** to download the activation file and save it on your computer.

Note: If your BVMS application is not installed on the same computer where your activation file is saved, transfer the activation file to the computer with the BVMS application.



Step 8: Upload the generated activation file

Go back to your BVMS application and click the **Open** button under **STEP 5** to upload your activation file. After successfully uploading your activation file, the license status changes to "activated" and your license information displays.



Now you can start using the full potential of your BVMS application and configure your system by adding cameras, for example.